

## #89920 INSTRUCTIONS FOR INSTALLING SANDPAPER



Have a  $2\frac{3}{4}$ " x  $17\frac{1}{2}$ " standard cut abrasive sheet. Raise one lever so it is at a right angle to the base. Insert the sheet of sandpaper under the gripper. Return the lever to the original position. Raise the second lever so it is at a right angle to the base. Wrap the sandpaper around the bottom of the base under the second gripper. Return the second lever to the original position.